


### Australian Hole Spacing

| Fibopost XTPost Length mm | TOP of post hole spacing down the post (hole number) |     |     |     |     |    |     |    |    |    |    |    |    |    |    |
|---------------------------|--|-----|-----|-----|-----|----|-----|----|----|----|----|----|----|----|----|
|                           | 1  | 2   | 3   | 4   | 5   | 6  | 7   | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 |
| 1350                      | 25   | 130 | 100 | 100 | 100 | 60 | 120 | 75 | 75 | 80 | 70 |    |    |    |    |
| 1500                      | 25   | 130 | 100 | 100 | 100 | 60 | 120 | 75 | 75 | 80 | 70 | 75 | 60 | 95 |    |
| 1650                      | 25   | 130 | 100 | 100 | 100 | 60 | 120 | 75 | 75 | 80 | 70 | 75 | 60 | 95 |    |
| 1800                      | 25   | 130 | 100 | 100 | 100 | 60 | 120 | 75 | 75 | 80 | 70 | 75 | 60 | 95 |    |
| 2100                      | 25   | 130 | 100 | 100 | 100 | 60 | 120 | 75 | 75 | 80 | 70 | 75 | 60 | 95 | 85 |

Nominal Hole Spacing 1800mm Fibopost 600XTPost . Measured from the top of the post. Holes Ø8mm nominal.

### Australian Hole Spacing



### New Zealand Hole Spacing

#### New Zealand Hole spacing

| Fibopost XTPost Length mm | TOP of post hole spacing down the post (hole number) |     |     |     |     |     |     |     |     |     |
|---------------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|                           | 1  | 2   | 3   | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
| 1350                      | 25   | 175 | 180 | 150 | 125 | 125 | 125 |     |     |     |
| 1500                      | 25   | 175 | 180 | 150 | 125 | 125 | 125 | 100 |     |     |
| 1650                      | 25   | 175 | 180 | 150 | 125 | 125 | 125 | 100 |     |     |
| 1800                      | 25   | 175 | 190 | 150 | 125 | 115 | 100 | 100 | 100 | 100 |
| 2100                      | 25   | 175 | 190 | 150 | 125 | 115 | 100 | 100 | 100 | 100 |